

PORSHE 997 MICROPHONE INSTALL

On the 997 it requires an extra microphone to be installed for Bluetooth to work. This install requires the Porsche 319 (2) wire handsfree microphone (right of steering column, blue connector). The 315 (4) wire microphones which is the Bluetooth and Bose amplifier microphones (left of steering column, 2 mics in 1, white connector). If only 1 of the microphones is installed, person on receiving end of phone call will hear very low and tinny audio.

INSTALLATION:

1. Before installing T-harness into vehicle, you need to run an extra wire for 2nd microphone
2. In T-harness remove white plug from harness going into radio
3. Pull cover off of connector to expose pins for wires.
4. Pins 2 and 8 need to be removed from harness.
5. With extra coax cable provided, plug clear wire in to pin 2 (microphone feed)
6. Plug black wire of coax cable into pin 8 (microphone return)
7. Plug T-harness into vehicle, run wires to steering column
8. Remove screws from underside of steering column
9. Gently pull up on top of column, unplug Bose amplifier microphone. Remove cover
10. Remove Bose microphone and install 997 (4) wire in its place.
11. Install 997 (2) wire microphone in right side of cover
12. Plug coax cable with orange heatshrink into right microphone
13. Plug other coax into blank inserts of Bose microphone harness
14. White wire of coax to white wire of microphone
15. Black wire of coax to black wire of microphone
16. Put together and test