


FreeGIG

Video and Navigation in motion interface for Chrysler MyGIG Radios

For passenger and off-road use only. User must obey all State and Federal regulations. Do not get distracted !!!

Operation Instructions

To Activate in-motion Feature	Fig. 1 - Video In Motion
Flip the supplied in-motion switch to ON	
DVD and Navigation can now be used while the vehicle is moving. NOTE: Route guidance does not work accurately while switch is on. Shut off the switch for route guidance.	



Agreement: End user agrees to use this product in compliance with all State and Federal laws. NAV-TV Corp. Would not be held liable for misuse of it's product.
If you do not agree, please discontinue use immediately and return product to place of purchase.
This product is intended for off-road use and passenger entertainment only.

FreeGIG

Video and Navigation in motion interface for Chrysler MyGIG Radios

For passenger and off-road use only. User must obey all State and Federal regulations. Do not get distracted !!!

Installation Instructions – Jeep JK

Remove Radio	Fig. 2 - Radio Removal (Jeep JK depicted)
<ol style="list-style-type: none">1. Pop upper and lower covers. Clips are at the rear of the top cover and top of the lower cover.2. Remove (4) 7mm screws holding radio, A/C trim.3. Pull trim just enough to gain access to radio. No need to remove A/C Controls.4. Remove (4) 7mm screws securing radio, Remove radio.	
WARNING !!!	Fig. 3 - STRAY CLIP
<p>1. Metal clips used on the radio trim tend to enter the radio face once trim is removed. Inspect the radio trim, if a clip is missing it is IN THE RADIO FACE !!! Use needle-nose fliers to pull the stray clip through the clip opening on the radio.</p>	
Wiring	Fig. 4 - Car Wiring
<ol style="list-style-type: none">1. Unplug Factory connector, connect to supplied Plug and play harness, reconnect all connectors.2. Connect 8-pin MOLEX connector to FreeGIG.3. Mount the included toggle switch.3. Re-assemble the vehicle, test for functionality.	